



## INSPECTION

### NOTICE:

When using a vise, do not overtighten it.

### INSPECT STEERING RACK

- (a) Using a dial indicator, check the rack for runout and for teeth wear and damage.

**Maximum runout: 0.30 mm (0.0118 in.)**

- (b) Check the back surface for wear and damage.