

## FUEL PUMP ON-VEHICLE INSPECTION

SF10Y-01


### 1. CHECK FUEL PUMP OPERATION

- (a) Connect a hand-held tester to the DLC3.
- (b) Turn the ignition switch ON, and push the hand-held tester main switch ON.

#### NOTICE:

**Do not start the engine.**


- (c) Select the active test mode on the hand-held tester.
- (d) Please refer to the hand-held tester operator's manual for further details.



- (e) If you have no hand-held tester, connect the positive (+) lead from the battery to terminal 1 of the connector, and the negative (-) lead to terminal 2.

#### NOTICE:

- **These test must be done quickly (within 10 seconds) to prevent the coil from burning out.**
- **Keep the fuel pump as far away from the battery as possible.**
- **Always do switching on the battery side.**



- (f) Check that there is pressure in the fuel inlet hose.

#### HINT:

- There are 2 fuel pumps. They usually operate alternately every time the ignition switch is turned ON and OFF.
- If there is fuel pressure, you will hear the sound of fuel flowing.

If there is no pressure, check these parts:

- Fusible link
- Fuses
- EFI main relay
- Fuel pump
- Fuel pump relay
- Fuel pump resistor
- ECM
- Wiring connections

- (g) Turn the ignition switch OFF.
- (h) Disconnect the hand-held tester from the DLC3.

**2. INSPECT FUEL PUMP RESISTANCE**

Using an ohmmeter, measure the resistance between the terminals.

**Resistance:**

**0.2 – 3.0 Ω at 20 °C (68 °F)**

If the resistance is not as specified, replace the fuel pump and/or set plate.

**3. CHECK FUEL PRESSURE**

- Check the battery voltage is 10 – 14 V.
- Disconnect the negative (-) terminal cable from the battery.
- Purchase a new fuel tube and take out the fuel tube connector from its pipe.

**Part No.**


**LHD 23901-32020**

**RHD 23901-32010**


- Disconnect the fuel tube connector from the fuel main pipe on the vehicle side.

**CAUTION:**

- Perform disconnecting operations of the fuel tube connector (quick type) after observing the precautions. (See page FI-1).
- As there is retained pressure in the fuel pipe line, prevent it from splashing inside the engine compartment.



- Install SST (pressure gauge) as shown in the illustration by using SST and fuel tube connector.  
SST 09268-41250, 09268-45012
- Wipe off any splattered gasoline.



- Connect the hand-held tester to the DLC3.  
(See step 1. (a) to (e) above)
- Reconnect the negative (-) terminal cable to the battery.
- Turn the ignition switch ON.
- Measure the fuel pressure.

**Fuel pressure:**

**Approx. 285 kPa (2.9 kgf/cm<sup>2</sup>, 41 psi)**

If pressure is high, replace the fuel pressure regulator.  
If pressure is low, check these parts:

- □ Fuel hoses and connections
- □ Fuel pump
- □ Fuel filter
- □ Fuel pressure regulator

(k) □ Remove the hand-held tester from the DLC3.

(l) □ Start the engine.

(m) □ Measure the fuel pressure at idling.

**Fuel pressure:**

**Approx. 218 kPa (2.2 kgf/cm<sup>2</sup>, 31 psi)**

If pressure is not as specified, check the vacuum sensing hose and fuel pressure regulator.

(n) □ Stop the engine.

(o) □ Disconnect the vacuum hose from the pressure regulator and block with a plug.

(p) □ Start the engine.

**Fuel pressure:**

**Approx. 285 kPa (2.9 kgf/cm<sup>2</sup>, 41 psi) or more**

If pressure is not as specified, check the fuel pump, pressure regulator and/or injectors.

(q) □ After checking fuel pressure, disconnect the negative (-) terminal cable from the battery and carefully remove the SST to prevent gasoline from splashing.

SST 09268-45012

(r) □ Reconnect the negative (-) terminal cable to the battery.

(s) □ Check for fuel leaks. (See page FI-1)