

# Kick-down Switch Circuit


## CIRCUIT DESCRIPTION

The kick-down switch is turned ON when the accelerator pedal is depressed beyond the full throttle opening and sends signals to Engine and ECT ECU.

When the kick-down switch is turned ON, the Engine and ECT ECU controls gear shifting according to the programmed shift diagrams.

If a short circuit develops in the kick-down switch, the Engine and ECT ECU disregards the kick-down signals and controls shifting at the normal shift points.

## WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 Check KICK DOWN SW signal.

**When using hand-held tester:****PREPARATION:**

- Remove the DLC3 cover.
- Connect a hand-held tester to the DLC3.
- Turn the ignition switch ON and hand-held tester main switch ON.

**CHECK:**

Read the KICK DOWN SW signal on the hand-held tester.

**OK:**

Accelerator Pedal	KICK DOWN SW signal
Fully depressed (kick-down SW is ON)	ON
Released (kick-down SW is OFF)	OFF

**When not using hand-held tester:****PREPARATION:**


Turn the ignition switch ON.

**CHECK:**

Measure voltage between terminal KD of Engine and ECT ECU connector and body ground when accelerator pedal is fully depressed or not.

**OK:**

Accelerator Pedal	Voltage
Fully depressed (kick-down SW is ON)	Below 1V
Released (kick-down SW is OFF)	10 - 14 V




OK

Proceed to next circuit inspection shown in problem symptoms table (See page DI-19)

NG

**2** Check kick-down switch.



**PREPARATION:**

Disconnect the kick-down switch connector.

**CHECK:**

Check continuity at each terminal of kick-down switch connector.

**OK:**

Kick-down Switch	Specified continuity
ON	Continuity
OFF	No continuity

**NG** Replace kick-down switch

**OK**

**3** Check harness and connector between Engine and ECT ECU and kick-down switch, kick-down switch and body ground (See page N-30).

**NG** Repair or replace the harness or connector.

**OK**

Check and replace Engine and ECT ECU (See page N-30).