


<b>DTC</b>	<b>15</b>	<b>Air Duct Sensor Circuit (Driver Side)</b>
------------	-----------	--

**CIRCUIT DESCRIPTION**

This sensor detects the register temperature and sends the appropriate signals to the A/C control assembly.


DTC No.	Detection Item	Trouble Area
15	Open or short in duct sensor circuit.	<ul style="list-style-type: none"> <li>• Duct sensor.</li> <li>• Harness or connector between duct sensor and A/C control assembly.</li> <li>• A/C control assembly.</li> </ul>

**WIRING DIAGRAM**



## INSPECTION PROCEDURE

- 1 Check voltage between terminals TFAL (RHD:TFAR) and SG of A/C control assembly connector.

**PREPARATION:**

Remove A/C control assembly with connectors still connected.

**CHECK:**

- (a) Turn ignition switch to ON.
- (b) Check voltage between terminals TFAL (THAR) and SG of A/C control assembly connector at each register temperature. ( ): RHD models

**OK:****Voltage**

at 25°C (77°F): 1.8 - 2.2V

at 50°C (122°F): 0.8 - 1.2V

**HINT:**

As the temperature increases, the voltage decreases.


NG

Go to step 2.

OK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-780). However, if DTC 15 is displayed, check and replace A/C control assembly.

- 2 Check duct sensor.

**PREPARATION:**

Remove duct sensor (See page AC-97).

**CHECK:**

Check resistance between terminals of duct sensor connector at each temperature.

**OK:****Resistance**

at 0°C (32°F): 14.5 - 19.0 kΩ

at 25°C (77°F): 4.8 - 5.2 kΩ

at 50°C (122°F): 1.6 - 2.0 kΩ

**HINT:**

As the temperature increases, the resistance decreases.

NG

Replace duct sensor.

OK

3 Check harness and connector between A/C control assembly and duct sensor (See page IN-30).

NG

Repair or replace harness or connector.

OK

Check and replace A/C control assembly.