

INSPECTION


1. INSPECT AIR FLOW METER RESISTANCE

Using an ohmmeter, measure the resistance between terminals THA and E2.

Resistance:

-20°C (-4°F)	10 – 20 kΩ
0°C (32°F)	4 – 7 kΩ
20°C (68°F)	2 – 3 kΩ
40°C (104°F)	0.9 – 1.3 kΩ
60°C (140°F)	0.4 – 0.7 kΩ

If the resistance is not as specified, replace the air flow meter.



2. INSPECT AIR FLOW METER OPERATION

- Connect the air flow meter connector.
- Connect the negative (-) terminal cable to the battery.
- Using a voltmeter, connect the positive (+) tester probe to terminal VG, and negative (-) tester probe to terminal E21.
- Turn the ignition switch ON.
- Blow air into the air flow meter, and check that the voltage fluctuates.

If operation is not as specified, replace the air flow meter.

- Turn the ignition switch OFF.
- Disconnect the negative (-) terminal cable from the battery.
- Disconnect the air flow meter connector.