

<b>DTC</b>	<b>B1231 / 31</b>	<b>Jam protection limit switch circuit on driver door</b>
------------	-------------------	---

<b>DTC</b>	<b>B1233 / 33</b>	<b>Jam protection limit switch circuit on passenger door</b>
------------	-------------------	--

<b>DTC</b>	<b>B1235 / 35</b>	<b>Jam protection limit switch circuit on rear right door</b>
------------	-------------------	---

<b>DTC</b>	<b>B1237 / 37</b>	<b>Jam protection limit switch circuit on rear left door</b>
------------	-------------------	--

## CIRCUIT DESCRIPTION

These DTCs are output when a malfunction of limit switch within power window motor is detected.

DTC No.	DTC Detection Condition	Trouble Area
B1231/31	No change in limit switch more than 2.0 seconds even if operating glass down when limit switch is OFF (window glass is fully closed)	<ul style="list-style-type: none"> <li>• Jam protection limit switch</li> <li>• Wireharness</li> </ul>
B1233/33		
B1235/35		
B1237/37		

### HINT:

Please refer to power window control system of BE section for switch inspection, and to each door system of DI section for wireharness inspection.