


DTC	C1241 / 41	IG Power Source Circuit
------------	-------------------	--------------------------------

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1241 / 41	Detection of either of conditions 1. or 2.: 1. Vehicle speed is 3 km/h (1.9 mph) or more and voltage of ECU terminal IG remains at below 9.5 V for more than 10 sec. 2. While the condition that the solenoid relay is ON continues, ECU terminal IG1 voltage becomes 9.5 V or less, and the condition that the contact point of the solenoid relay is OFF continues for 0.2 sec. or more.	<ul style="list-style-type: none"> • Battery • Charging system • Power source circuit

WIRING DIAGRAM




N

F16935

INSPECTION PROCEDURE

1	Check ECU-IG fuse.
----------	---------------------------



PREPARATION:

Remove the ECU-IG fuse from instrument panel J/B.

CHECK:

Check continuity of ECU-IG fuse.

OK:

Continuity

NG Check for short circuit in all the harness and components connected to ECU-IG fuse (See attached wiring diagram).

OK

2	Check battery voltage.
----------	-------------------------------

OK:

Voltage: 10 - 14 V

NG Check and repair the charging system (See Pub. No. RM677E on page CH-1).

OK

3	Check voltage of the ECU-IG power source.
----------	--

In case of using the hand-held tester:

PREPARATION:


- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch to ON, and push the hand-held tester main switch to ON.
- (c) Select the DATALIST mode on the hand-held tester.

CHECK:

Check the voltage condition output from the ECU displayed on the hand-held tester.

OK:

"Normal" is displayed.



In case of not using the hand-held tester:

PREPARATION:

Remove the skid control ECU with the connectors still connected.

CHECK:

- (a) Turn the ignition switch to ON.
- (b) Measure voltage between terminals IG1 and GND of skid control ECU connector.

OK:


Voltage: 10 - 14 V

OK

Check and replace skid control ECU.

NG

4 Check continuity between terminal GND of skid control ECU connector and body ground.



CHECK:

- Disconnect the 2 connectors from the skid control ECU.
- Measure resistance between terminals GND of skid control ECU connector and body ground.

OK:

Resistance: 1 Ω or less

NG

Repair or replace harness or connector.

OK

Check for open circuit in harness and connector between skid control ECU and battery (See page IN-31).