

<b>DTC</b>	<b>Always ON</b>	<b>ABS &amp; TRC ECU Malfunction</b>
------------	------------------	--------------------------------------


**CIRCUIT DESCRIPTION**

DTC No.	DTC Detecting Condition	Trouble Area
Always ON	Either of the following 1., 2. or 3. is detected: 1. Voltage of ECU terminal IG1 remains at more than 17 V. 2. The ECU connectors are off from the ECU. 3. There is a malfunction in the ECU internal circuit.	<ul style="list-style-type: none"> <li>• Battery</li> <li>• Charging system</li> <li>• Power source circuit</li> <li>• ABS &amp; TRC ECU</li> </ul>

Fail safe function:

If any trouble occurs in the ECU, the ECU cuts off current to the ABS solenoid relay and prohibits ABS controls and the brake system becomes normal.

**WIRING DIAGRAM**



N

F07542

## INSPECTION PROCEDURE

1 Check that the ABS & TRC ECU connectors are securely connected to the ABS & TRC ECU.

NO

Connect the connector to the ABS & TRC ECU.

YES

2 Is DTC output?

Check DTC on [page DI-153](#).

YES

Repair circuit indicated by the code output.

NO

3 Is normal code displayed?

YES

Check ABS solenoid relay. Check for short circuit in harness and connector between relay and check connector ([See page N-30](#)).

NO

4 Does ABS warning light go off?

YES

Check for open and short circuit in harness and connector between ECU-IG fuse and ABS & TRC ECU ([See page N-30](#)).

NO

**5 Check battery positive voltage.****CHECK:**

Check the battery positive voltage.

**OK:**

**Voltage: 10 – 14 V**

**NG****Check and repair the charging system.****OK**

**Check for short circuit in harness and connector between combination meter and ABS & TRC ECU, combination meter and check connector (See page IN-30).  
Check ABS solenoid relay circuit (See page DI-163).**