


<b>DTC</b>	<b>C1233 / 33, C1234 / 34</b>	<b>Yaw Rate Sensor Circuit</b>
------------	-------------------------------	--------------------------------

## CIRCUIT DESCRIPTION


DTC No.	DTC Detecting Condition	Trouble Area
C1233 / 33	<p>When any of the following 1. through 4. is detected:</p> <ol style="list-style-type: none"> <li>1. ECU terminal IG1 voltage is 9.5 to 17.2 V and the yaw rate sensor voltage is continuously out of the range from 0.25 to 4.75 V for 1 sec. or more.</li> <li>2. ECU terminal IG1 voltage is 9.5 to 17.2 V and the yaw rate sensor open circuit detection signal remains ON for 1 sec. or more.</li> <li>3. ECU terminal IG1 voltage is 9.5 to 17.2 V and the yaw rate sensor power source voltage remains out of the range from 4.4 to 5.6 V for 1 sec. or more.</li> <li>4. Momentary interruption of the yaw rate sensor signal occurs 10 times or more.</li> </ol>	<ul style="list-style-type: none"> <li>• Yaw rate sensor</li> <li>• Yaw rate sensor circuit</li> </ul>
C1234 / 34	<p>When the condition that yaw rate sensor voltage is 4.4 V to 5.6 V and YD malfunction signal of yaw rate sensor is ON continued for 5 sec. or more.</p>	

WIRING DIAGRAM



INSPECTION PROCEDURE

- 1 Perform zero point calibration of the yaw rate sensor (See page DI-3).



## 2 Is DTC still output?


Check DTC on page DI-3.

NO

No problem.

YES

## 3 Check output value of the yaw rate sensor.



In case of using the hand-held tester:

### PREPARATION:

- Remove the 2 bolts and yaw rate sensor with connector still connected.
- Connect the hand-held tester to the DLC3.
- Turn the ignition switch to ON and push the hand-held tester main switch to ON.
- Select the DATALIST mode on the hand-held tester.

### CHECK:

Check that the yaw rate value of the yaw rate sensor displayed on the hand-held tester changes. Place the yaw rate sensor vertically to the ground and turn the sensor pivoted on its center.

### OK:

Yaw rate value must be changing.

In case of not using the hand-held tester:

### PREPARATION:

- Remove the yaw rate sensor with the connector still connected to it.
- Turn the ignition switch to ON.

### CHECK:

Measure voltage between terminals YAW2 (1) - GYAW (5), and terminals YD (6) - GYAW (5) of the yaw rate sensor.

### OK:


Terminals 1 and 5 (YAW2 - GYAW)	About 2.42 V - 2.58 V
Terminals 6 and 5 (YD - GYAW)	About 4.5 V - 5.3 V

NG

Replace yaw rate sensor.

OK

#### 4 Check voltage between terminals YD and GND of skid control ECU.



#### PREPARATION:

Remove the skid control ECU with the connectors still connected.

#### CHECK:

- Turn the ignition switch to ON.
- Measure voltage between terminals YD and GND of skid control ECU.

#### OK:

Voltage: 4.5 - 5.3V

OK

Check and replace skid control ECU.

NG

#### 5 Check for open and short circuit in harness and connector between yaw rate sensor and skid control ECU (See page N-31).

NG

Repair or replace harness or connector.

OK

Check and replace skid control ECU.