BO28U-01

REASSEMBLY

At the time of reassembly, please pay attention to the following item.

- 1. CLEAN BUMPER COVER
- (a) Using a heat light, heat the adhesive tape remaining on the bumper cover to 40 60 °C (104 140 °F).


NOTICE:

Do not heat the bumper cover excessively.

(b) After operation in (a) above, wipe off remaining adhesive tape from bumper cover using a shop rag.

NOTICE:

- Thoroughly remove the adhesive tape. Otherwise, remaining tape will adversely affect attaching of the bumper moulding.
- Avoid removing remaining tape with a screwdriver or a like. Otherwise, scratches will occur to the bumper groove, which will cause poor attachment.
- (c) Clean the bonding surface.



2. INSTALL NEW BUMPER MOULDING

- (a) Align bosses A, B and C of a new bumper moulding to the bumper cover.
- (b) Attach the bumper moulding along the groove, starting from boss C to bosses D, E and F.
- (c) Attach the bumper moulding from boss F all the way to the rear right edge of the bumper cover, along the groove. Engage the rear end of bumper moulding with the bumper cover.
- (d) Attach the bumper moulding starting from boss A all the way to the rear right edge of bumper cover, along the groove. Engage the rear end of bumper moulding with the bumper cover.

NOTICE:

- Attach the bumper moulding using the groove upper edge as the datum.
- Carry out the bumper moulding bonding job at an ambient temperature of 20 °C (68 °F) or more. If the ambient temperature is below 20 °C (68 °F), heat the bumper cover groove area and bumper moulding with a heat light to 20 30 °C (68 86 °F) and then attach the bumper moulding.
- When the bumper moulding release sheet is removed, make sure that no dirt or dust can get onto the uncoated area.