

<b>DTC</b>	<b>B1232 / 32</b>	<b>Jam protection pulse switch circuit on driver door</b>
------------	-------------------	---

<b>DTC</b>	<b>B1234 / 34</b>	<b>Jam protection pulse switch circuit on passenger door</b>
------------	-------------------	--

<b>DTC</b>	<b>B1236 / 36</b>	<b>Jam protection pulse switch circuit on rear right door</b>
------------	-------------------	---

<b>DTC</b>	<b>B1238 / 38</b>	<b>Jam protection pulse switch circuit on rear left door</b>
------------	-------------------	--

## CIRCUIT DESCRIPTION

These DTCs are output when a malfunction of pulse switch within power window motor is detected.

DTC No.	DTC Detecting Condition	Trouble Area
B1232/32	No change in pulse switch more than 2.0 seconds even if opening glass down when limit switch is OFF (window glass is fully closed).	<ul style="list-style-type: none"> <li>• Jam protection pulse switch</li> <li>• Wireharness</li> </ul>
B1234/34		
B1236/36		
B1238/38		

### HINT:

Please refer to power window control system of BE section for switch inspection, and to each door system of DI section for wireharness inspection.