

DTC	B1221 / 21	Power window switch circuit on driver door
------------	-------------------	---

DTC	B1222 / 22	Door lock switch circuit on driver door
------------	-------------------	--

DTC	B1223 / 23	Power window switch circuit on passenger door
------------	-------------------	--

DTC	B1224 / 24	Door lock switch circuit on passenger door
------------	-------------------	---

DTC	B1225 / 25	Power window switch circuit on rear right door
------------	-------------------	---

DTC	B1226 / 26	Power window switch circuit on rear left door
------------	-------------------	--

DTC	B1241 / 41	Body ECU switch circuit diagnosis
------------	-------------------	--

CIRCUIT DESCRIPTION

These DTC notify how switch works as follows:

If DTC is not output when operating switch, it means failure of switch contact. If DTC is output when not operating switch, it means stick of switch. When something wrong is found by this diagnosis, inspect each switch. Then, replace the switch if there is a problem, or check the wireharness if there is no problem.

DTC No.	DTC Detecting Condition	Trouble Area
B1221/21	Stick of either of the power window master switch (except window lock switch)	<ul style="list-style-type: none"> • Power window master switch • Wireharness
B1222/22	Stick of door key lock and unlock switch	<ul style="list-style-type: none"> • Door lock control switch • Door key lock and unlock switch • Wireharness
B1223/23	Stick of power window switch or door lock control	<ul style="list-style-type: none"> • Power window switch • Door lock control switch • Wireharness

B1224/24	Stick of door key lock and unlock switch	<ul style="list-style-type: none"> • Door lock control switch • Door key lock and unlock switch • Wireharness
B1225/25	Stick of power window switch	<ul style="list-style-type: none"> • Power window switch • Wireharness
B1226/26	Stick of power window switch	<ul style="list-style-type: none"> • Power window switch • Wireharness
B1241/41	Stick of switch	<ul style="list-style-type: none"> • Luggage compartment door opener switch • Luggage compartment door lock and unlock switch • Wireharness

HINT:

Please refer to BE section for switch inspection, and to each door system of DI section for wireharness inspection.