


<b>DTC</b>	<b>P1755/68</b>	<b>Linear Solenoid for Lock-up Control Circuit Malfunction (SLU Solenoid Valve)</b>
------------	-----------------	---




**CIRCUIT DESCRIPTION**

The amount of current flow to the solenoid is controlled by the (\*) duty ratio of the Engine and ECT ECU output signal. The higher the duty ratio becomes, the higher the lock-up hydraulic pressure becomes during the lock-up operation.

(\*) Duty Ratio

The duty ratio is the ratio of the period of continuity in one cycle. For example, if A is the period of continuity in one cycle, and B is the period of non-continuity, then




(\*)

$$\text{Duty Ratio} = \frac{A}{A + B} \times 100 (\%)$$

BE4056


D00160

DTC No.	DTC detection condition	Trouble Area
P1755/68	(a) or (b) condition below is detected for 1 second or more. (a) SLU output signal ON time is 3.3 m sec. or more. (b) SLU output signal ON time is 100 m sec. or less. (frequency: 300 Hz)	<ul style="list-style-type: none"> <li>• Open or short in shift solenoid valve SLU circuit</li> <li>• SLU solenoid valve</li> <li>• Engine and ECT ECU</li> </ul>




**HINT:**

- Refer to the chart for the wave form between terminals SLU<sup>+</sup> and SLU<sup>-</sup> when lock-up function is not operating.



- Refer to the chart for the wave form between terminals SLU<sup>+</sup> and SLU<sup>-</sup> when lock-up function is operating.


# WIRING DIAGRAM



D04914

**INSPECTION PROCEDURE**

**1 Check SLU solenoid valve.**



**Check solenoid resistance:**

**PREPARATION:**

- (a) Jack up the vehicle.
- (b) Remove the oil pan.
- (c) Disconnect the solenoid connector.

**CHECK:**

Measure the resistance between terminals 1 and 2.

**OK:**

**Resistance: 5.1 – 5.5 Ω at 20 °C (68 °F)**

**Check solenoid operation:**

**PREPARATION:**

- (a) Jack up the vehicle.
- (b) Remove the oil pan.
- (c) Remove the SLU solenoid valve.

**CHECK:**

Connect the positive (+) lead from the battery to terminal 2 and negative (-) lead to terminal 1.

**OK:**

When B+ is applied.	Valve moves in  direction in the illustration on the left.
When B+ is cut off.	Valve moves in  direction in the illustration on the left.

**NG** Replace SLU solenoid valve.

**OK**

**2 Check harness and connector between SLU solenoid valve and Engine and ECT ECU (See page IN-30).**

**NG** Repair or replace the harness or connector.

**OK**

**Check and replace the Engine and ECT ECU (See page IN-30).**