


## Tilt Position Sensor Circuit

### CIRCUIT DESCRIPTION


The tilt position is sent to the ECU as a voltage signal from the position sensor. A constant 5 V is supplied to terminal 2 of sensor. The voltage at terminal 3 varies with position and is input to the ECU.

### WIRING DIAGRAM



### INSPECTION PROCEDURE

- 1 Check voltage between terminals TIS and E1 of ECU connector.



#### PREPARATION:

- Remove ECU with connectors still connected.
- Remove tilt position sensor with connector still connected.

#### CHECK:

Measure voltage between terminals TIS and E1 of ECU connector, while turning the tilt position sensor lever slowly by hand from raised side to lowered side.

#### OK:

#### Voltage:

**Fully raised: Below 1 V**

**Fully lowered: 4 - 6 V**


#### HINT:

As the lever is turned, the voltage should increase gradually without interruption.

**OK** Proceed to next circuit inspection shown on the problem symptoms table (See page DI-203).

**NG**

**2 Check tilt position sensor.**



**PREPARATION:**  
Disconnect tilt position sensor connector.

**CHECK:**  
Measure the resistance between terminals VC and E1 of tilt position sensor connector.

**OK:**  
**Resistance:** 4 - 6 kΩ

**CHECK:**  
Measure the resistance between terminals TIS and E1 of tilt position sensor connector, while turning the tilt position sensor lever slowly by hand from raised side to lowered side.

**OK:**  
**Resistance:**  
**Fully raised:** Below 100 Ω  
**Fully lowered:** 4 - 6 kΩ

**HINT:**  
As the lever is turned, the resistance should increase gradually without interruption.

**NG** Replace tilt position sensor.

**OK**

**3 Check harness and connectors between ECU and tilt position sensor (See page IN-30).**

**NG** Repair or replace harness or connector.

**OK**

**Check and replace ECU.**