



## ROOF PANEL (ASSY)

### REMOVAL



1. Heat the brazed area of the front body pillar, and scrape off the brazing with a wire brush.

*HINT: Be careful not to overheat the front body pillar.*

2. Grind off the roof panel tip at the quarter panel arc brazing connection with a cut grinder.



