


REPLACEMENT

1. DRAIN ENGINE COOLANT


- (a) Remove the radiator cap.

CAUTION:

To avoid the danger of being burned, do not remove the radiator cap while the engine and radiator are still hot, as fluid and steam can be blown out under pressure.



- (b) Disconnect the reservoir outlet hose and drain the coolant from reservoir.
 (c) Loosen the radiator drain plug and drain the coolant.



- (d) Loosen the 2 engine drain plugs and drain the coolant.

HINT:

To prevent the coolant from spraying over the cylinder block, connect the rubber hose (inside diameter 6 – 8 mm) in the market to the union pipe under the drain plug.

- (e) Close the drain plugs.

Torque:

Engine drain plug 13 N·m (130 kgf·cm, 9 ft·lbf)

- (f) Connect the reservoir outlet hose.

2. FILL ENGINE COOLANT

HINT:

- Use of improper coolants may damage engine cooling system.
- Use "Toyota Long life Coolant" or equivalent and mix it with plain water according to the manufacturer's directions.
- Using of coolant which includes more than 50 % (freezing protection down to -35°C (-31°F)) or 60 % (freezing protection down to -50°C (-58°F)) of ethylene-glycol is recommended but not more than 70 %.

NOTICE:

- **Do not use an alcohol type coolant or plain water alone.**
 - **The coolant should be mixed with plain water (preferably demineralized water or distilled water).**
- (a) Remove the plug from the water pump, and slowly fill the system with the coolant.
 - (b) Fill the reservoir with the coolant.
 - (c) Start the engine, and bleed the cooling system.
 - (d) Refill the reservoir with coolant until it reaches the "FULL" line.
 - (e) Install the reservoir cap.

3. CHECK ENGINE COOLANT FOR LEAKS**4. CHECK ENGINE COOLANT SPECIFIC GRAVITY CORRECTLY**