



DISPOSAL

1. **FULLY EXTEND SHOCK ABSORBER ROD**
2. **DRILL HOLE TO DISCHARGE GAS FROM CYLINDER**

Using a drill, make a hole in the cylinder, as shown in the illustration to discharge the gas inside.

CAUTION:

- **When drilling, chips may fly out, work carefully.**
- **The gas is colorless, odorless and non-poisonous.**