

## INSTALLATION

### 1. INSTALL UPPER SUSPENSION ARM TO BODY

(a) Install the upper suspension arm and 2 bolts.

**Torque: 127 N·m (1,300 kgf·cm, 94 ft·lbf)**

(b) Connect ABS speed sensor wire harness clamp to the upper suspension arm with the bolt.

**Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)**

### 2. INSTALL FRONT PNEUMATIC CYLINDER (See page SA-26)

### 3. CHECK ELECTRONIC MODULATED AIR SUSPENSION SIGNAL (See page DI-66)

### 4. CHECK FRONT WHEEL ALIGNMENT (See page SA-5)