



REMOVAL

REMOVE ROOF DRIP SIDE FINISH CENTER MOULDING

- (a) Apply protective tape to the outside circumference of the moulding.
- (b) Using a heat light, heat the moulding to 40 – 60 °C (104 – 140 °F).

NOTICE:

Do not heat the moulding excessively.

- (c) Using a scraper, remove the moulding by slowly separating the attached portion starting from the rear edge.

HINT:

Tape the scraper tip before use.