## **INSTALLATION**

HINT:

For step 1 to 4, refer to page SR-18.

- 1. INSTALL SPIRAL CABLE
- 2. INSTALL UPPER AND LOWER COLUMN COVERS
- 3. INSTALL STEERING WHEEL
- 4. INSTALL STEERING WHEEL PAD

CENTURY (RM676E)

RS013-18