

REMOVAL

1. **REMOVE FRONT WHEEL**
2. **REMOVE FRONT FENDER LINER**
3. **DISCONNECT CONNECTOR**
4. **DISCONNECT HEIGHT CONTROL SENSOR LINK**

Remove the nut and disconnect the height control sensor link from the shock absorber lower bracket.

5. **REMOVE FRONT HEIGHT CONTROL SENSOR AND ACCELERATION SENSOR**

Remove the 2 nuts and front height control sensor and acceleration sensor.