## **REASSEMBLY**

Reassembly is in the reverse order of disassembly (See page AC-44).

AC0OB-01