


# ELECTRICAL WIRING ROUTING

## Position of Parts in Instrument Panel

[RHD]



- A 12 A/C Control Assembly
- A 13 A/C Control Assembly
- A 14 A/C Control Assembly
- A 15 A/C Control Assembly
- A 16 A/C Evaporator Temp. Sensor
- A 17 A/C Room Temp. Sensor
- A 18 A/C Solar Sensor
- A 19 ABS and Traction ECU
- A 20 ABS and Traction ECU
- A 21 ABS and Traction ECU
- A 22 Accel Position Sensor
- A 23 Accelerator Pedal SW
- A 24 Air Inlet Control Servo Motor
- A 25 Air Mix Control Servo Motor (Driver Side)
- A 26 Air Mix Control Servo Motor (Front Passenger Side)
- A 27 Air Vent Mode Control Servo Motor (Driver Side)
- A 28 Air Vent Mode Control Servo Motor (Front Passenger Side)
- A 29 Airbag Sensor Assembly
- A 30 Airbag Sensor Assembly
- A 31 Airbag Sensor Assembly
- A 32 Airbag Squib (Front Passenger's Airbag Assembly)
- A 33 Airbag Squib (Steering Wheel Pad)
- A 34 Automatic Light Control Sensor

- B 2 Blower Controller
- B 3 Blower Controller
- B 4 Blower Motor
- B 5 Body ECU
- B 6 Body ECU
- B 7 Body ECU
- B 8 Body ECU