

INSTALLATION

Installation is in the reverse order of removal (See page BR-19).

HINT:

- Before installation, adjust length of brake booster push rod (See page BR-24).
- After installation, fill the brake reservoir with brake fluid and bleed brake system (See page BR-4).
- Check for leaks, check and adjust brake pedal (See page BR-6).