

ANTENNA LOCATION

BE14E-01

NOTICE:

- **Check that no external noises exist. Always carry out this check. Otherwise, the noise source cannot be identified correctly, resulting in a wrong determination.**
- **When taking noise preventive measures, begin.**

Noise source of power system

Ignition system	Charge system	Other electrical units
(1) Ignition plug (2) High tension cord (3) Distributor (4) Engine control computer	(1) Ripple generated at contacting point between alternator commutator and carbon brush	(1) Commutators such as wiper and blower motors (2) Starter and switch st starting the engine (3) Contact of fuel pump (4) Sparking of selector switch (5) Horn (6) Contact of flasher (7) Loose contact of wiring harness (8) Static electricity generated by tires and alternator V-belt (9) Contact of stop light switch

