



INSTALLATION

1. INSTALL FUEL PRESSURE PULSATION DAMPERS

Using SST, install 2 new gaskets, the rear fuel pipe and pulsation damper. Install the 2 pulsation dampers.

SST 09612-24014 (09617-24011)

Torque:

40 N·m (410 kgf·cm, 29 ft·lbf)

34 N·m (350 kgf·cm, 24 ft·lbf) for SST

HINT:

Use a torque wrench with a fulcrum length of 30 cm (11.81 in.).

2. INSTALL V-BANK COVER