


# ABS & BA & TRC & VSC SYSTEM

## HOW TO PROCEED WITH TROUBLESHOOTING

DI0W3-11

Troubleshoot in accordance with the procedure on the following pages.



**Fail-Safe Function:**

When a failure occurs in the ABS & BA & TRC & VSC system, the respective ABS & VSC warning light is lit and the operation of ABS & BA & TRC & VSC is prohibited.