

# INSPECTION

INSPECT NEUTRAL START SWITCH CONTINUITY (See page DI-47)