



COMPONENTS


RADIO RECEIVER ASSEMBLY



P

I10654

DISC PLAYER ASSEMBLY



RADIO SPEAKER ASSEMBLY

Speaker Assembly FR No.2 (Tweeter)

Front Speaker Assembly No.1

Door Frame Upper Garnish

Side Trim Board Front Cover

Front Door Arm Rest

Door Lock Control Knob

Door Arm Rest Cap

Front Door Trim Panel

Side Trim Board Front No.2 Cover

Courtesy Light

Door Inside Handle

Front Door Trim Upper Panel

Speaker Assembly RR No.2 (Tweeter)

Rear Door Frame Garnish

Side Trim Board Rear Cover

Rear Door Arm Rest

Door Lock Control Knob

Door Arm Rest Cap

Rear Speaker Assembly No.1

Rear Speaker Grille

Door Arm Rest Cap

Door Inside Handle

Side Trim Board Rear No.2 Cover

Rear Door Trim Upper Panel


Courtesy Light

Rear Door Trim Panel

Stereo Component Speaker Assembly RR (Woofer)



P

STEREO COMPONENT AMPLIFIER ASSEMBLY



P

RADIO SWITCH & VOLUME ASSEMBLY



P