

## INSTALLATION

### 1. INSTALL CAMSHAFT TIMING OIL CONTROL VALVES

- (a) Install 2 new O-rings to oil control valves.
- (b) Install the 2 oil control valves and 2 bolts.

**Torque: 8.0 N·m (80 kgf·cm, 64 ft·lbf)**

- (c) Connect the 2 connectors.

### 2. INSTALL WATER PUMP ASSEMBLY AND WATER BY-PASS JOINT FR ([See page CO-7](#))

- 3. INSTALL AIR CLEANER ASSEMBLY LH AND RH WITH AIR FLOW METER
- 4. INSTALL AIR CLEANER INLET
- 5. INSTALL V-BANK COVER