


POWER WINDOWS

Power windows with one-touch auto up/down function with jam protection mechanism are provided in all the doors as standard equipment.

- ❶ A jam protection mechanism is provided in all the doors as standard equipment on all models to ensure safety.
- ❷ The door windows can be raised and lowered by turning the ignition key in the key hole on the driver's side door.



DOOR LOCKS

- ❶ A door key-linked power door lock system is provided as standard equipment on all models, enabling all the doors to be locked and unlocked from the door key cylinder is operation.
- ❷ An impact-sensing door lock release system is provided as standard equipment on all models. In the event of a collision, this system senses the impact and releases the door locks.
- ❸ Wireless door lock remote control is provided as standard equipment on all models. This system enables all the doors to be locked and unlocked, and the door windows to be lowered from the outside of the vehicle.
- ❹ The luggage door unlock button provided on the transmitter enables the luggage door to be unlocked from the outside of the vehicle.

