

15. Rear fog light indicator does not turn on.

INSPECTION PROCEDURE

1 Check of multiplex communications.

CHECK:

Are communications between combination meter and body ECU normal?
(Refer to flowchart No. 1)

No

Communication failure.
Faulty wiring harness.

Yes

2 Bulb check.

CHECK:

Are rear fog light bulbs normal?

No

Faulty bulb.

Yes

3 Electrical continuity check of meter circuit plate.

CHECK:

Is it continuity between meter circuit plate No. B and b3 terminals?

Yes

Faulty meter ECU.

No

4 Check of connector connection.**CHECK:**

Are meter ECU connectors D and E connected firmly?

No**Faulty connector connection.****Yes****Faulty meter circuit plate.**