

## **DISASSEMBLY**

1. REMOVE SIDE DEFROSTER NOZZLE NO.1 AND NO.2
2. REMOVE SIDE DEFROSTER NOZZLE NO.1 DUCT
3. REMOVE SIDE DEFROSTER NOZZLE NO.2 DUCT
4. REMOVE DEFROSTER NOZZLE ASSEMBLY
5. REMOVE NO.4 HEATER TO RESISTER DUCT
6. REMOVE NO.3 HEAT TO RESISTER DUCT
7. REMOVE GLOVE COMPARTMENT DOOR LOCK STRIKER PANEL
8. REMOVE COIN BOX ASSEMBLY AND COIN BOX RETAINER
9. REMOVE OUTER MIRROR SWITCH
10. REMOVE LIGHT CONTROL SENSOR
11. REMOVE COOLER THERMISTOR