


# CRUISE MAIN Indicator Light Circuit

## CIRCUIT DESCRIPTION

When the cruise control main switch is turned ON, CRUISE MAIN indicator light lights up.

## WIRING DIAGRAM



**INSPECTION PROCEDURE**

1 Check combination meter (See page DI-454).

NG

Replace combination meter.

OK

Check and replace Engine and ECT ECU (See page IN-30).