

## INSPECTION

1. INSPECT BLOWER MOTOR CIRCUIT (See page DI-844)
2. INSPECT BLOWER RESISTOR RESISTANCE (See page DI-844)
3. INSPECT SMOKE SENSOR CIRCUIT (See page DI-853)
4. INSPECT MODE CONTROL SERVO MOTOR CIRCUIT (See page DI-855)

### 5. INSPECT EVAPORATOR FINS FOR BLOCKAGE

If fins are clogged, clean them with compressed air.

#### NOTICE:

**Never use water to clean the evaporator.**

### 6. CHECK EVAPORATOR FITTING FOR CRACKS SCRATCHES

Repair as necessary.