

## INSPECTION

1. REMOVE ECM FROM BODY BRACKET
2. INSPECT ECM  
(See [page DI-20](#))
3. REINSTALL ECM