

# POWER TILT AND POWER TELESCOPIC STEERING COLUMN

## HOW TO PROCEED WITH TROUBLESHOOTING

DI2LW-02

Perform troubleshooting in accordance with the procedure on the following page.

