

## INSPECTION

### 1. INSPECT FINS FOR BLOCKAGE

If fins are clogged, clean them with compressed air.

#### NOTICE:

Never use water to clean the evaporator.

### 2. CHECK FITTING FOR CRACKS & SCRATCHES

Repair as necessary.

### 3. INSPECT EVAPORATOR TEMPERATURE SENSOR CIRCUIT (See page DI-789)