



## **REMOVAL**

## REMOVE ROOF DRIP SIDE FINISH MOULDING

Hole at the lead edge of the roof drip side finish moulding, disconnect the engagement using the moulding remover, and remove the moulding.