



INSPECTION

1. REAR WINDOW PRINTED TYPE ANTENNA

NOTICE:

- Use a dry soft cloth to clean the glass, by wiping in the direction of heater wire so as not to damage the wires.
- Avoid use of the general detergent or glass cleaner.
- Wind aluminum foil to the tip of tester bar so as not to damage the heater wire during measurements and measure while giving the aluminum foil contact with the heater wire.

Give the tester bar contact with the printed type antenna and move slowly to find a faulty position where the circuit is electrically not continuous.

2. REAR WINDOW PRINTED TYPE ANTENNA

(See page BE-78)

