

INSTALLATION

1. INSTALL THROTTLE BODY ASSEMBLY

- (a) Install the LH and RH throttle body assembly and 8 bolts with 2 new gaskets.

Torque: 21 N·m (215 kgf·cm, 16 ft·lbf)

- (b) Connect the 2 water by-pass hose No.3, vacuum hose and air hose to each throttle body assembly.
(c) Connect the throttle position sensor connector and throttle control motor connector to each throttle body assembly.

2. INSTALL AIR CLEANER HOSE NO.1 AND NO.2 WITH INTAKE AIR RESONATOR

3. FILL ENGINE COOLANT

4. INSTALL V-BANK COVER