COMPONENT PARTS

AT0CP–02

COMPONENTS




O/D Brake Pack
Race
O/D Planetary Gear Unit
with O/D Direct Clutch
Assembled
Bearing & Race
Oil Pump
Bearing
Race
Snap Ring
Front Planetary Ring Gear
Bearing
Race
Snap Ring
2nd Coast
Brake Band
x 7
Race
◆ O–Ring
21 (215, 16)
Thrust Washer
Direct Clutch
Race
Bearing
O/D Support
Assembled Bearing
& Race
E–Ring
Forward Clutch
Pin
Assembled
Bearing &
Race
E–Ring
2nd Brake
Thrust Washer
Thrust Washer
2nd Brake Pack
25 (260, 19)
Race
Snap Ring
O/D Planetary
Ring Gear
Snap Ring
Thrust Washer
Planetary Sun Gear
Snap Ring
Bearing
2nd Brake Piston Sleeve
Output Shaft
No.1 One–Way
Clutch
Assembled
Bearing & Race
Race
Rear Planetary Gear
Front Planetary Gear
1st & Reverse Brake Pack
◆ Brake Drum Gasket
Bearing & Race
2nd Coast
Brake Cover
Spring
Rear Planetary Gear
Leaf Spring
2nd Coast Brake
Piston Assembly
◆ O–Ring
Snap Ring
N·m (kgf·cm, ft·lbf) : Specified torque
◆ Non–reusable part
Y
D04646