
BO2AD-01



DISASSEMBLY


1. REMOVE FRONT SEAT CUSHION SHIELD

 (a) Using a screwdriver, remove the power seat switch knobs.

HINT:

Tape the screwdriver tip before use.


(b) Remove the 6 screws and cushion shield, then disconnect the connector.



2. w/ Lumber support:

REMOVE LUMBER SUPPORT SWITCH


Remove the 2 screws and switch.



3. REMOVE FRONT SEAT INNER BELT

Remove the bolt and front seat inner belt.

4. REMOVE HEADREST




5. REMOVE REAR ASSIST GRIP

(a) Using a screwdriver, remove the 2 plugs.

HINT:

Tape the screwdriver tip before use.

(b) Remove the 2 bolts and assist grip.




6. RH passenger's side: REMOVE FRONT SEAT FOOT REST

(a) Using a screwdriver, remove the 2 hinge covers.


HINT:

Tape the screwdriver tip before use.

(b) Remove the 4 bolts and front seat foot rest, then disconnect the control cable.




(c) Remove the screw and seatback lock cover as shown in the illustration.




(d) Using a screwdriver, remove the seatback protector shaft bushings.

HINT:


Tape the screwdriver tip before use.




(e) Remove the center seatback cover as shown in the illustration.




(f) Remove the 4 nuts and front seatback foot rest frame.



- g) Remove the seatback lock holder.
 - (1) Using a drill, remove the 2 rivets.
 - (2) Remove the 4 nuts.



(h) Remove the 3 screws and limit switch.




7. REMOVE FRONT SEATBACK BOARD

Remove the 2 screws and front seatback board as shown in the illustration.


HINT:

Remove the seatback board in order A, B as shown in the illustration.




8. REMOVE FRONT SEATBACK ASSEMBLY

Remove the 4 bolts and front seatback assembly.



9. REMOVE FRONT SEAT CUSHION ASSEMBLY


Remove the 4 bolts and front seat cushion assembly.



10. LH seat only: REMOVE FRONT SEAT TRAY RAIL NO.2


- (a) Remove the 4 bolts.
- (b) Remove the front seat tray rail No.2 and seat wire.

CENTURY (RM676E)




11. REMOVE FRONT SEAT CUSHION FRAME

- (a) Disengage the front seat cushion cover as shown in the illustration.
- (b) Remove the front seat cushion frame.
- 12. REMOVE FRONT SEAT CUSHION COVER




13. REMOVE POWER SEAT SWITCH

Remove the 2 screws and power seat switch.




14. REMOVE HEADREST SUPPORTS

Remove the headrest supports as shown in the illustration.




15. RHD passenger's seat: REMOVE SEATBACK LOCK STRIKER

- (a) Remove the 2 screws and seatback lock striker.
- (b) Employ the same manner described above to the other side.




16. RHD passenger's seat: REMOVE FRONT SEAT CENTER ARMREST LINK

- (a) Remove the screw and link.
- (b) Employ the same manner described above to the other side.




17. REMOVE FRONT SEATBACK FRAME

Disengage the hooks and remove the front seatback frame as shown in the illustration.




18. REMOVE FRONT SEAT RECLINING ADJUSTERS

- (a) Remove the 4 bolts and reclining adjusters.
- (b) Remove the 2 seat fabrics from the reclining adjusters.
- (c) Remove the 2 bolts and reclining adjuster connecting rod and pipe.




19. REMOVE POWER SEAT RECLINING MOTOR

- (a) Remove the 3 screws and power seat reclining motor with bracket from the reclining adjuster.
- (b) Remove the 3 screws and power seat reclining motor from the bracket.




20. w/ Lumber support: REMOVE LUMBER SUPPORT ASSEMBLY

- (a) Remove the 3 bolts and lumber support assembly.
- (b) Remove the lumber support spacer.




21. REMOVE FRONT POWER ADJUSTER SHIELD

Remove the 2 screws and front power adjuster shield.




22. REMOVE REAR VERTICAL ADJUSTER

- (a) Remove the 2 bolts, 2 nuts and rear vertical adjuster.
- (b) Remove the bolt and inner seat track upper reinforcement from the rear vertical adjuster.




23. REMOVE POWER SEAT REAR VERTICAL MOTOR

(a) Using pliers, hold the screw stopper to fix the rear vertical jack screw and remove the nut.



- (b) Remove the power seat rear vertical motor and 2 washers.
- (c) Remove the 2 screws and screw support bushing.


CENTURY (RM676E)




24. REMOVE FRONT VERTICAL ADJUSTER ASSEMBLY Remove the 2 bolts, nut and front vertical adjuster.

25. REMOVE POWER SEAT FRONT VERTICAL MOTOR

- (a) Remove the front vertical inner adjuster.
- (b) Remove the front vertical travel pipe.
- (c) Remove the 2 bolts and motor support bracket.




- (d) Remove the 2 bolts and front vertical outer adjuster.
- (e) Remove the 3 bolts and power seat front vertical motor.




26. REMOVE POWER SEAT SLIDE MOTOR

(a) Remove the 2 bolts and slide the front seat outer track as shown in the illustration.



(b) Using pliers, hold the horizontal jack screw and remove the nut.



- (c) Unfasten the plastic nut.
- (d) Remove the front seat outer and inner tracks from the power seat slide motor.
- (e) Remove the 2 screws, 2 washers and seat track No.1 bracket.